


Model RC Rupture Disks are designed to fit Standard AAR 2" safety vents.

1. Remove old rupture disk and inspect condition of safety vent to ensure clean flat sealing surfaces.
2. Check rating of new ZOOK Rupture Disk. Make sure it conforms to tank car pressure requirements and matches the safety vent style.
3. Install new ZOOK Rupture Disk WITH THE FLOW DIRECTION ARROW POINTING UP, or away from the tank. The rupture disk should be concentric within the safety head bolting. See Illustration.
4. Before completing assembly, inspect safety vent bolts and nuts. They should be corrosion free and clean. If not, use new bolts and nuts.
5. Assemble the safety vent head, lubricate, and finger-tighten the bolts. Cross-tighten bolts in two or three stages until all bolts show a uniform torque of 15 foot-pounds.



www.zookdisk.com

Serving America, Central & South America
16809 Park Circle Drive, Chagrin Falls,
Ohio 44022 USA
Toll Free: +1 800 543 1043
Phone: +1 440 543 1010
E-mail: sales@zookdisk.com

Serving Europe, Middle East & Africa
Navigation House, Bridge Street
Killamarsh, Sheffield,
S21 1AL UK
Phone: +44 (0) 1909 560999
E-mail: sales.europe@zookdisk.com

Serving Canada
4400 South Service Rd,
Burlington, Ontario L7L 5R8 CA
Toll Free: +1 800 370 6057
Phone: +1 905 681 2885
E-mail: sales.canada@zookdisk.com

Serving Asia Pacific
Unit No.23A-05, Menara Landmark, No.12,
Jalan Ngee Heng
80000 Johor Bahru, Johor, Malaysia
Phone: +60 (7) 2910099
E-mail: sales.asia@zookdisk.com